apuro

Soup Kettle

Instruction manual

Model
L715-A/L714-A

Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
    - Health and Safety at Work Legislation
    - BS EN Codes of Practice
    - Fire Precautions
    - IEE Wiring Regulations
    - Building Regulations
- DO NOT immerse the appliance in water.
- DO NOT clean with jet/pressure washers.
- DO NOT move or carry the appliance when it is switched on.
- DO NOT operate the appliance without water in the outer container.
- Keep the lid closed when not serving.
- Suitable for indoor use only.
- Always switch off and disconnect the power supply to the appliance when not in use.
- This appliance must only be used in accordance with these instructions and by persons competent to do so.
- This appliance is not suitable for use by children.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the power cord is damaged, it must be replaced by an Apuro agent or a recommended qualified technician in order to avoid a hazard.

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your Apuro product.

Pack Contents

The following is included:

- Apuro Soup Kettle
- Lid
- Magnetic label Strip x 1
- Contents labels x 13
- Instruction manual

Apuro prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your Apuro dealer immediately.

Installation

Position the soup kettle on a flat, stable surface.

Fit the Lid

1. Slot the lid on top of the appliance

⚠ **Note: The lid is hinged in the middle. Lift one half of the lid to access the container.**

Attaching Labels

1. Slide the relevant label into the magnetic label holder.
2. Attach the holder to the side of the appliance.

⚠ **Note: If the desired label is not included, simply write the name of the product on the reverse of one of the labels.**

Operation

1. Connect the appliance to the mains power supply.
2. Fill the outer container with approximately 600ml of water.
3. Carefully place the inner container into the appliance.

⚠ **Note: The inner container must NOT float, even when empty. If the container floats reduce the amount of water in the outer container.**

4. Fill the inner container with hot soup and close the lid.

⚠ **Note: If necessary, remove any excess water from the outer container.**

5. Set the temperature control. The temperature ranges from 1 (lowest) to 12 (highest).
6. The Power light will come on and the kettle will begin to heat up.

⚠ **Note: Kettle is not designed to heat food from cold.**

7. Reduce the temperature to maintain heat levels. To maintain temperature, Apuro recommend the lowest heat setting possible.
8. Use a suitable implement to remove the contents of the kettle. DO NOT tip the kettle to remove the contents.
9. To turn the appliance Off, set the Temperature Control to '0'.

⚠ **WARNING: Never move or carry the appliance when it is switched on or contains hot liquid.**

Cleaning, Care & Maintenance

- Always turn off and disconnect the appliance from the power supply before cleaning.
- Clean any spilt food on the appliance immediately.
- Use soapy water and a damp cloth to clean the exterior of the appliance.
- The inner container and lid are machine washable.
- Dry thoroughly after cleaning.

Troubleshooting

Fault	Probable Cause	Action
The unit is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug and lead are damaged	Call Apuro agent or qualified technician
	Fuse in the plug has blown	Replace the plug fuse
	Power supply	Check power supply
	Internal wiring fault	Call Apuro agent or qualified technician
Soup not heating up	Insufficient temperature setting	Increase temperature setting

Technical Specifications

Model	Voltage	Power	Current	Capacity (litres)	Weight	Dimensions w x d x h mm
L715	240V 50Hz	400W	1,9A	10	4,3 kgs	375 x 330 x 330
L714	240V 50Hz	400W	1,9A	10	4,3 kgs	375 x 330 x 330

Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed, using a dedicated earthing circuit.

If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

Apuro parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

Apuro products have been approved to carry the following symbol:

All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Apuro.

Every effort is made to ensure all details are correct at the time of going to press, however, Apuro reserve the right to change specifications without notice.

DECLARATION OF CONFORMITY

Equipment Type	**Soup Kettle**
Model	**L715-A, L714-A**
Legislation	**C-Tick** **AS/NZ 3820 Essential Safety Requirements for Low Voltage Electrical Equipment**
Standards	**EN 55014-1:2006** **EN 55014-2:1997+A1** **EN 61000-3-2:2006** **EN 61000-3-3:1995+A1+A2** **AS/NZS 60335.1:2002+A1,A2,A3** **As/NZS 60335.2.15:2002+A1,A2,A3,A4**
Producer Name	**Apuro**
Producer Address	**15 Badgally Road,** **Campbelltown,** **NSW 2560**

I, the undersigned, hereby declare that the equipment specified above conforms to the above Legislation and Standard(s).

Date	**09/03/11**
Signature	
Full Name	**Richard Cromwell**
Position	**Marketing Director**

apuro